



**General:**

---

Timeout: A 60 sec. timeout is started as soon as any button(s) are released. On timeout the setup is exited with no changes saved.

Red LED: Active during set-up:  
- Flashing in step 1  
- Steady in all other steps

Error conditions during operations:  
- Steady is showing hardware fault or indication pin out of range  
- Flashing is showing software fault

**Symbols:**

---

- ⓐ Push local key "I"
- ⓑ Push local key "II"
- ⓐ<sub>5s</sub> Hold key "II" for 5 sec

Simple representation of LED indication:



