


PULLER SETS

Manual


10 & 17½ Ton

10 ton manual puller set –

This puller set is just what you need for removing gears, bearings, etc. Includes pullers, attachments, and many accessories.



IPS10M



IPS17M

17½ ton manual puller set – The pullers and accessories in this set can be used for hundreds of applications including quick and easy maintenance involving removal and replacement of press-fit parts.

Manual Puller Set No.
Order No.

Set
Contents Pullers

Set
Contents Accessories

IPS10M
10 ton capacity
Wt., 53 lbs.

927 10 ton capacity Bi-Directional™ with 6¾" legs
1023 2 ton combination 2/3-jaw puller
1026 5 ton combination 2/3-jaw puller
1027 5 ton combination 2/3-jaw puller
1037 7 ton combination 2/3-jaw puller
1178 Slide hammer set

8075 Step plate adapter set
8044 Female threaded adapter set
8035 Female threaded adapter: ½"-20 x ⅝"-18
1151 Bearing cup pulling attachment
1121 Bearing pulling attachment
1122 Bearing pulling attachment
1123 Bearing pulling attachment
1101 15½" long puller legs for 927 (pr.)

IPS17M
17½ ton capacity
Wt., 116 lbs.

938 17½ ton capacity Bi-Directional™ puller w/9½" legs
1027 5 ton combo 2/3-jaw puller, with long jaws
1037 7 ton combination 2/3-jaw puller
1041 13 ton combination 2/3 jaw puller
1045 17½ ton 3-jaw puller

8075 Step plate adapter set
1105 22½" legs for 938
1130 Bearing pulling attachment
1151 Bearing cup pulling attachment
8038 Female adapter: ⅝"-18 F. x ¾"-16 F. (2)

PULLERS